



TIKKURILA

## SUPI LAUDESUOJA

PROTECTIVE OIL FOR SAUNA BENCH

**DESCRIPTION** Paraffin oil protection for wood surfaces against moisture and dirt.

**RECOMMENDED USES** Untreated or previously oiled wooden sauna benches.

**PRODUCT FEATURES** For untreated wood surfaces, e.g. sauna benches.

## SUPI LAUDESUOJA

### TECHNICAL DATA

<b>Colour Shades</b>	Colorless, deepens the color of the wood.
<b>Coverage</b>	8–15 m <sup>2</sup> /l, depending on the porosity of the surface.
<b>Can sizes</b>	0.25 l, 1 l
<b>Application method</b>	Apply with a brush or clean cloth.
<b>Drying time</b>	Ready to use when the oil has been absorbed into the wood. The speed of absorption depends on the porosity of the wood.
<b>Density (kg/l)</b>	0.8 kg/l, ISO 2811.
<b>Volume solids (%)</b>	100
<b>Storage</b>	Protect from frost.



# SUPI LAUDESUOJA

## APPLICATION INSTRUCTIONS

### Application conditions

The surface to be treated must be dry, the ambient temperature at least +5 °C and the relative humidity of air below 80%.

### Surface preparation

Wash dirty benches with Supi Saunapesu cleaning agent according to instructions, rinse thoroughly and let dry. Sand if necessary and remove the sanding dust.

### Application

Apply the sauna bench protection with a brush or clean cloth and allow the wood to absorb the oil. If the oil is absorbed immediately, repeat the treatment. Heat the sauna and wipe off the surplus oil with a clean cloth.

### Cleaning of tools

Clean the tools with water and soap. Clean tools with water. Clean tools with water and soap or Tikkurila Pensselipesu Tool Cleaner.

### Maintenance instructions

If needed, no earlier than in approx. 1 month from surface treatment:

Clean the surface with Supi Saunapesu (mix 0.1–0.2 l of Saunapesu with 5 l of water). Undiluted Supi Saunapesu can be used on dirt stains. For bleaching the sauna benches, use a 1:1 solution of Supi Saunapesu cleaning agent and water, leave for approx. 15 minutes and rinse thoroughly. Repeat the Supi Laudesuoja treatment if necessary.

### Environmental protection and waste disposal

Destroy liquid waste according to the local regulations for hazardous waste. Recycle empty, dry cans or dispose them of in accordance with local regulations.

The above information is not intended to be exhaustive or complete. The information is based on laboratory tests and practical experience, and it is given to the best of our knowledge. The quality of the product is ensured by our operational system, based on the requirements of ISO 9001 and ISO 14001. As manufacturer we cannot control the conditions under which the product is being used or the many factors that have an effect on the use and application of the product. We disclaim liability for any damages caused by using the product against our instructions or for inappropriate purposes. We reserve the right to change the given information unilaterally without notice.